



## Mounting Options

### 1 Floor Stand Mounting

USE M4 x 10mm PIN-IN-TORX  
BUTTON HEAD SCREWS PROVIDED.  
TIGHTEN USING PROVIDED  
TORX SCREWDRIVER




### 2 Counter Stand Mounting




USE M4 x 10mm PIN-IN-TORX  
BUTTON HEAD SCREWS PROVIDED.  
TIGHTEN USING PROVIDED  
TORX SCREWDRIVER

### 3 Wall Arm Mounting




USE M4 x 10mm PIN-IN-TORX  
BUTTON HEAD SCREWS PROVIDED.  
TIGHTEN USING PROVIDED  
TORX SCREWDRIVER

### 4 Direct Mounting To Wall



MOUNTING SCREWS  
NOT PROVIDED


### Optional Add-On: Portrait To Landscape Rotation Plate



USE M4 x 10mm PIN-IN-TORX BUTTON  
HEAD SCREWS PROVIDED TO  
FIX TO ROTATION PLATE. TIGHTEN USING  
PROVIDED TORX SCREWDRIVER.  
USE SCREWS PROVIDED WITH ROTATION PLATE  
TO SECURE TO STAND or ARM


Placing Tablet with Connector to Dock Station

1




USE KEY TO UNLOCK THE LOCK.  
REMOVE KEY

2




ALIGN CONNECTOR TO DOCK STATION

3



APPLY LIGHT PRESSURE.  
LATCH WILL ENGAGE


4



PUSH LOCK BUTTON TO SECURE  
TABLET TO DOCK STATION


Removing Tablet with Connector from Dock Station

1




PRIOR TO PULLING LATCH,  
UNLOCK LOCK USING KEY

2



PULL LATCH FORWARD

3





GENTLY PULL UP TO RELEASE

4



Tablet Charge PD Compatible


Tablet Data and Charge PD Compatible




IN THE BOX







Keys




Hardware Kit



PowerMove Dock Station




5




NOTE:  
TABLET AND CONNECTOR SHOULD BE AT  
ROOM TEMPERATURE FOR BEST RESULTS

6




FOR BEST PERFORMANCE ALLOW  
CONNECTOR TO BOND TO TABLET FOR 12 HOURS.

IN THE BOX



Alcohol Wipes



PowerMove Connector